



Microfiber Laundering Instructions

Proper Care & Maintenance



FABRIC SOFTENER

- Never Use Fabric Softener
- Fabric Softener Will Clog and Ruin Yarn



WASHING

- Maximum Washing Temperature 194F/90C
- Do Not Use Strong Alkaline Detergent
- Normal Agitation Cycle
- Normal Rinse Cycle



BLEACHING

- Periodic Light Bleaching Only
- Oxygen Bleach Approved
- Liquid Bleach in Moderation



SPINNING

- Unlike Cotton Microfiber Does Not Absorb Water
- Water is Stored in the Cells of the Yarn
- Centrifugal Spinning Removed 95% of Moisture
- Extended Spin Cycles Will Reduce Drying Time



DRYING

- Maximum Drying Temperature 140F/60C
- Tumble Dry at Low Temperature
- Do Not Over Dry
- Extreme temperature Will Damage Yarn
- Less Dry Time Will Extend Life of Yarn